



Self-Training

Courseware Includes:

1. Protected Searchable Training PDF
2. Hardcopy Printed Training Manual
3. PSpice Lab Files
4. PSpice Advanced Analysis Webinar
5. PSpice Analog Behavioral Model Webinar1
6. PSpice Analog Behavioral Model Webinar2
7. VIDEO: -

- AC Analysis of Mosfet
- Bipolar junction transistor characteristics
- BJT Characteristics
- DC Analysis of a MOSFET
- Diode circuit and dc sweep analysis
- Diode circuit and model editor
- Frequency response of a mosfet amplifier
- Introduction1
- Introduction2
- Introduction3
- Pmos and depletion mode devices
- Transient Analysis of a BJT Amplifier

| | |
|--|-----------|
| Lesson 1: Building a Design for Simulation | 11 |
| Learning Objectives..... | 11 |
| Creating a New Project..... | 11 |
| Project Templates | 12 |
| New projects may be based on an existing design or a template with Capture | 12 |
| The PSpice Project..... | 13 |
| Available Libraries | 13 |
| What Is a "Part" in EDA? | 14 |
| Placing a Part | 15 |
| Placing Multiple Instances of Parts | 17 |
| Rotating and Mirroring Parts..... | 18 |
| Connecting Parts Electrically | 19 |
| Valid Connections | 19 |
| Placing Wires..... | 20 |
| Rubber banding..... | 20 |
| Placing Symbols | 22 |
| Editing Properties | 22 |
| Creating Custom Filters..... | 23 |
| Assigning a Net Alias | 24 |
| Lab 1-1: Creating a RC Circuit | 25 |
| Lab Objectives..... | 25 |
| Creating a New PSpice Project..... | 25 |
| Placing the Voltage Source | 27 |
| Placing the Resistors..... | 27 |
| Placing the Capacitor..... | 28 |
| Connecting the Components..... | 28 |
| Placing the Analog Ground Symbol..... | 29 |
| Assigning the Capacitor Reference Designator..... | 29 |
| Labeling Nets..... | 29 |
| Assigning a DC Value of 10V to the Voltage Source..... | 29 |
| Saving the File | 29 |
| Lab 1-2: Property Spreadsheet Editor | 30 |
| Lab Objectives..... | 30 |
| Editing Properties for Multiple Parts..... | 30 |
| Additional Lab: Creating a Custom Filter..... | 30 |
| Lesson 2: DC Bias Point Analysis..... | 31 |
| Lesson Objectives..... | 31 |
| Setting Up a Simulation Profile..... | 32 |
| The Simulation Settings Dialog Box..... | 32 |
| Running a Bias Point Simulation | 35 |
| Examine the Output File and Bias Display | 35 |
| Value Multipliers..... | 37 |
| Lab 2-1: Simulating a DC Bias Point..... | 38 |
| Lab Objectives..... | 38 |

| | |
|--|-----------|
| Creating a Bias Point Simulation Profile..... | 38 |
| Running the Simulation | 39 |
| Viewing Simulation Output..... | 39 |
| Additional Lab Exercise | 40 |
| Lesson 3: DC Sweep Analysis..... | 41 |
| Learning Objectives..... | 41 |
| What is DC Sweep Analysis? | 41 |
| DC Sweep Settings and Options..... | 41 |
| Data Collection | 42 |
| Examining Results in Probe..... | 44 |
| Setting up Sources..... | 44 |
| Markers | 45 |
| Customizing the Probe Display | 46 |
| Multiple Y-axes..... | 47 |
| Lab 3-1: Performing a DC Sweep..... | 48 |
| Lab Objectives | 48 |
| Setting Up the Simulation..... | 48 |
| Setting Up Data Collection and Probe Windows | 49 |
| Analyzing the Results in the Probe Window | 49 |
| Plotting Traces From the Menu | 50 |
| Plotting Traces Using Markers | 51 |
| Customizing the Probe Display | 53 |
| Changing Axis and Grid Settings | 54 |
| Additional Lab Exercise | 55 |
| Lesson 4: AC Sweep Analysis..... | 56 |
| Lesson Objectives | 56 |
| What Does AC Sweep Analysis Do?..... | 56 |
| AC Sweep Simulation Setup..... | 56 |
| Configuring Sources | 56 |
| Setting up the AC Sweep Simulation Profile | 58 |
| Viewing Simulation Results in Probe..... | 59 |
| Trace Names | 61 |
| Functions..... | 61 |
| Lab 4-1: Performing an AC Sweep Analysis..... | 62 |
| Lab Objectives | 62 |
| Creating a New PSpice Project..... | 62 |
| Setting Up and Starting an AC Sweep Analysis..... | 63 |
| Running the Simulation and Viewing Results..... | 64 |
| Displaying a Bode Plot | 65 |
| Lesson 5: Simulating a Text Netlist..... | 66 |
| Learning Objectives..... | 66 |
| Running a Simulation From A Circuit File | 66 |
| PSpice Circuit File Format..... | 67 |
| Interpretation of Device Types and Pin Order..... | 68 |
| Device Instantiations..... | 70 |

| | |
|---|-----------|
| Comments in a Circuit File..... | 71 |
| Model Statements | 71 |
| Subcircuit Statements | 72 |
| Lab 5-1: Creating a Text Netlist..... | 72 |
| Lab Objectives..... | 72 |
| Creating a PSpice Netlist..... | 72 |
| Running PSpice Using the Netlist..... | 73 |
| Lesson 6: Stimulus Editor | 74 |
| Learning Objectives..... | 74 |
| Stimulus Editor | 75 |
| Vstim, Istim, Digstim Symbols | 75 |
| Defining a Stimulus | 76 |
| Configuring Stimulus Files..... | 80 |
| Where have all the Files Gone?..... | 80 |
| Review of Adding a Stimulus..... | 81 |
| Lab 6-1: Creating a Sine Wave Stimulus | 81 |
| Lab Objectives..... | 81 |
| Placing the VSTIM Symbol | 81 |
| Running the Simulation..... | 83 |
| Lab 6-2: Creating a Piecewise Linear Stimulus | 84 |
| Lab Objectives..... | 84 |
| Creating a Piece-wise Linear Source..... | 84 |
| Correcting Mistakes..... | 86 |
| Additional Exercises..... | 86 |
| Lesson 7: Transient Analysis..... | 87 |
| Learning Objectives..... | 87 |
| What is Transient Analysis?..... | 87 |
| Setting up a Simulation | 87 |
| Transient Sources | 90 |
| PSpice Runtime Settings | 90 |
| Scheduling Option Values..... | 91 |
| Lab 7-1: Transient Analysis on RC.DSN | 92 |
| Lab Objectives..... | 92 |
| Lab 7-2: Transient on BUFFER.DSN | 95 |
| Lab Objectives..... | 95 |
| Editing the Design File..... | 95 |
| Verifying Simulation Set Up..... | 95 |
| Plotting the Y Axis | 96 |
| Lab 7-3: Extending a Simulation..... | 98 |
| Lab Objectives..... | 98 |
| Re-running the Buffer Transient Simulation..... | 98 |
| Additional Exercise | 98 |
| Lesson 8: Resolving Simulation Errors..... | 98 |
| Learning Objectives..... | 98 |
| Common Circuit Errors and Solutions | 99 |

| | |
|---|------------|
| Multiple Bias Points..... | 100 |
| Simulation Accuracy..... | 100 |
| Non-convergence | 101 |
| Newton-Raphson..... | 101 |
| Error Tolerances/Convergence Criteria | 101 |
| Common Causes of Convergence Failure | 102 |
| Troubleshooting DC and Bias Point Convergence Failure | 102 |
| Troubleshooting Transient Convergence Failure | 103 |
| Scheduling Option Values | 105 |
| Lab 8-1: Floating Node..... | 106 |
| Lab Objectives | 106 |
| Opening the nodcpath Project..... | 106 |
| Identifying Errors..... | 106 |
| Correcting Errors..... | 106 |
| Lab 8-2: Resolution..... | 107 |
| Lab Objectives | 107 |
| Opening the stpcplg Project..... | 107 |
| Setting Up and Running Simulation | 107 |
| Correcting Errors..... | 107 |
| Lab 8-3: Scheduling Runtime Settings | 107 |
| Lab Objectives | 107 |
| Opening the stpcplg Circuit | 108 |
| Lab 8-4: Convergence Error | 108 |
| Lab Objectives | 108 |
| Open the Project and Run the Simulation..... | 108 |
| Correcting Simulation Errors..... | 110 |
| Lab 8-5: Discontinuities..... | 111 |
| Lab Objectives | 111 |
| Lab 8-6: No Limit | 112 |
| Lab Objectives | 112 |
| Lesson 9: Transformers..... | 113 |
| Learning Objectives | 113 |
| Linear Transformers..... | 113 |
| Linear Transformer Circuit..... | 113 |
| Non-linear Transformers..... | 114 |
| Coupling Inductors..... | 115 |
| Lab 9-1: Linear Transformer | 116 |
| Lab Objectives | 116 |
| Constructing the Circuit..... | 117 |
| Configuring the Coupling Symbol..... | 117 |
| Configuring the Simulation..... | 118 |
| Lab 9-2: Non-linear Transformers..... | 119 |
| Lab Objectives | 119 |
| Create a Non-linear Transformer | 119 |
| Additional Exercise..... | 120 |

| | |
|--|------------|
| Lesson 10: Parametric Analysis | 120 |
| Learning Objectives..... | 120 |
| What Does Parametric Analysis Do? | 120 |
| Preparing a Design for Parametric Analysis | 121 |
| Parametric Setup..... | 121 |
| Viewing Parametric Results in Probe..... | 123 |
| Using Cursors | 123 |
| Lab 10-1: Parametric Analysis | 124 |
| Lab Objectives..... | 124 |
| Create and Define Cval Part..... | 125 |
| Using a Global Parameter as a Property Value | 126 |
| Viewing the Output in the Probe Window | 127 |
| Additional Exercise | 129 |
| Lesson 11: Editing a Model..... | 130 |
| Learning Objectives..... | 130 |
| Creating a Model with the Model Editor..... | 130 |
| Text Mode..... | 131 |
| Graphical Mode | 131 |
| Local and Global Model Libraries | 132 |
| Referencing a Model | 133 |
| Library Indexing | 134 |
| Extracted Parameters | 134 |
| Lab 11-1: Editing a Model | 135 |
| Lab Objectives..... | 135 |
| Creating Project Zener.opj..... | 135 |
| Running the Simulation..... | 137 |
| Lab 11-2: Extracting a Model..... | 137 |
| Lab Objectives..... | 137 |
| Creating a New Library and Model..... | 137 |
| Entering Specification Data..... | 139 |
| Extracting PSpice Model Parameters | 144 |
| Getting a Symbol | 145 |
| Configuring New Parts and Models | 146 |
| Additional Exercise | 147 |
| Lesson 12: Adding New Parts | 147 |
| Learning Objectives..... | 147 |
| Types of Simulation Models | 147 |
| Creating Subcircuits from Schematics | 148 |
| Creating the Subcircuit | 148 |
| Differences Between Models and Subcircuits..... | 149 |
| Creating Symbols for Simulation Models..... | 149 |
| Creating Symbol Libraries | 149 |
| Creating a New Part in a Library..... | 150 |
| Part and Symbol Editor Palette..... | 151 |
| PSpice Template | 152 |

| | |
|--|------------|
| Configuring Symbol and Model Libraries..... | 153 |
| Lab 12-1: Subcircuit from the Buffer Circuit..... | 153 |
| Lab Objectives..... | 153 |
| Create Buffer2 Project..... | 154 |
| Rename Schematic Folder to Create Subcircuit..... | 154 |
| Create Netlist..... | 154 |
| Lab 12-2: Creating a Part with the Wizard..... | 156 |
| Lab Objectives..... | 156 |
| Create Library Part..... | 156 |
| View the Part..... | 157 |
| Using the New Symbol..... | 157 |
| Lab 12-3: Creating a Part from Scratch..... | 159 |
| Lab Objectives..... | 159 |
| Creating a New Library File..... | 159 |
| Drawing the Graphics..... | 161 |
| Editing the Properties..... | 162 |
| Using the Part in a Design..... | 162 |
| Lesson 13: Temperature Analysis..... | 163 |
| Learning Objectives..... | 163 |
| Temperature Coefficients..... | 163 |
| Temperature Attributes..... | 164 |
| Extracting Temperature Models..... | 166 |
| Resistors and Temperature..... | 166 |
| Temperature in Simulation..... | 167 |
| Lab 13-1: Temperature Sweep..... | 167 |
| Lab Objectives..... | 167 |
| Create Thermostat Circuit..... | 167 |
| Configure Simulation Profile..... | 168 |
| Additional Exercise..... | 169 |
| Lesson 14: Monte Carlo Analysis..... | 169 |
| Learning Objectives..... | 169 |
| What Does Monte Carlo Analysis Do?..... | 169 |
| Device and Lot Tolerances..... | 170 |
| Configuring Monte Carlo Analysis..... | 170 |
| Options Within the Simulation Settings Dialog Box..... | 171 |
| Viewing Output File, Probe Plot, and Histograms..... | 172 |
| Lab 14-1: Performing a Monte Carlo Analysis..... | 173 |
| Lab Objectives..... | 173 |
| Creating the Pressure Project..... | 173 |
| Setting Up the Analysis..... | 175 |
| Examining the Results..... | 176 |
| Lab 14-2: Viewing Monte Carlo Histograms..... | 178 |
| Lab Objectives..... | 178 |
| Preparing the Circuit..... | 179 |
| Setting up the Analysis..... | 179 |

| | |
|---|------------|
| Creating the Histogram..... | 179 |
| Changing the Number of Histogram Divisions..... | 180 |
| Viewing the Center Frequency Distribution of the Filter | 181 |
| Additional Exercise | 182 |
| Lesson 15: Hierarchical Blocks and Symbols..... | 182 |
| Learning Objectives..... | 182 |
| Pros & Cons of Hierarchical Blocks | 183 |
| Pros & Cons of Hierarchical Symbols | 183 |
| Connectors and Ports | 184 |
| Creating Hierarchical Blocks | 185 |
| Navigating the Hierarchy | 185 |
| Hierarchical Netlist..... | 186 |
| Lab 15-1: Hierarchical Block | 187 |
| Lab Objectives..... | 187 |
| Creating the Top Level Design..... | 187 |
| Creating the Lower Level Design..... | 190 |
| Simulating and Viewing Results | 191 |
| Lab 15-2: Hierarchical Symbols..... | 191 |
| Lab Objectives..... | 191 |
| Preparing a Design to be Symbolized | 191 |
| Creating a Hierarchical Symbol | 192 |
| Setting up the Project to Use Hierarchy | 194 |
| Using the New Symbol in a Design | 196 |
| Lab 15-3: Creating a Hierarchical Netlist | 197 |
| Lab Objectives..... | 197 |
| Open Hier_clip Design..... | 197 |
| Creating a Hierarchical Netlist | 199 |
| Lesson 16: Analog Behavioral Modeling..... | 201 |
| Learning Objectives..... | 201 |
| Analog Behavioral Modeling Defined | 201 |
| Using ABM Devices..... | 202 |
| Using ABM Devices by Reference | 202 |
| Lab 16-1: ABM Evaluate with Wired Inputs | 203 |
| Lab Objectives..... | 203 |
| Define Symbol Properties..... | 203 |
| Lab 16-2: ABM Evaluate by Reference | 204 |
| Lab Objectives..... | 204 |
| Editing the Design | 204 |
| Lab 16-3: Frequency Table | 205 |
| Lab Objectives..... | 205 |
| Placing and Defining Symbols | 205 |
| Lab 16-4: Voltage-Controlled Oscillator | 207 |
| Lab Objectives..... | 207 |
| Entering a Circuit into a New Project..... | 207 |
| Lesson 17: Simulating Digital Circuits | 208 |

| | |
|--|------------|
| Learning Objectives | 208 |
| How Digital Components are Modeled | 209 |
| Placing Digital Parts | 209 |
| Wiring Digital Parts | 209 |
| Digital Power and Ground | 210 |
| Setting up Digital Simulations | 212 |
| Viewing Digital Results | 213 |
| Lab 17-1: Counter Example | 214 |
| Lab Objectives | 214 |
| Creating the Circuit..... | 214 |
| Creating the Simulation Profile | 215 |
| Running the Simulation | 215 |
| Viewing the Results in the Probe Window | 216 |
| Lab 17-2: Counter with Bus..... | 217 |
| Lab Objectives | 217 |
| Placing the Bus..... | 217 |
| Connecting the Bus | 217 |
| Running the Simulation | 217 |
| Lesson 18: Mixed Analog and Digital..... | 218 |
| Learning Objectives | 218 |
| Mixed Simulation..... | 218 |
| Lab 18-1: Mixed A/D Oscillator..... | 219 |
| Lab Objectives | 219 |
| Opening the A/D Circuit..... | 219 |
| Additional Exercise..... | 220 |
| Lesson 19: Measurements..... | 220 |
| Learning Objectives | 220 |
| How Measurements Work | 220 |
| Measurement Format | 221 |
| Measurement Example..... | 223 |
| Plot Window Templates..... | 225 |
| Lab 19-1: Using the Risetime Measurement | 226 |
| Lab Objectives | 226 |
| Creating the Goals Project | 226 |
| Configuring a Transient Analysis | 226 |
| Running the Simulation | 226 |
| Configuring and Running the Performance Analysis | 227 |
| Lab 19-2: Creating a Measurement | 228 |
| Lab Objectives | 228 |
| Opening the Buffer Project | 228 |
| Adding a Trace..... | 228 |
| Defining the Measurement..... | 228 |
| Using the New Goal Function..... | 229 |
| Lab 19-3: Creating Plot Window Templates | 230 |
| Lab Objectives | 230 |

| | |
|--|------------|
| Opening the Buffer Circuit..... | 230 |
| Using the New Plot Window Template..... | 232 |
| Lesson 20: Worst Case Analysis | 233 |
| Learning Objectives..... | 233 |
| Configuring the Analysis..... | 235 |
| Lab 20-1: Biased BJT Amplifier - Working WC..... | 236 |
| Lab Objectives..... | 236 |
| Creating the Circuit | 237 |
| Creating the Simulation Profile..... | 237 |
| Running the Simulation..... | 239 |
| Analyzing the Results..... | 240 |
| Lab 20-2: Mislabeled Worst-Case | 242 |
| Lab Objectives..... | 242 |
| Editing the Rbmod Model | 242 |
| Running the Worst Case Analysis..... | 242 |
| What We Are Seeing | 243 |
| Lesson 21: Noise Analysis | 244 |
| Lesson Objectives..... | 244 |
| What Is Noise Analysis? | 244 |
| Definitions | 244 |
| Calculating Output and Input Noise..... | 244 |
| Setting up Noise Analysis | 244 |
| Lab 21-1: Noise Analysis | 248 |
| Lab Objectives..... | 248 |
| Configuring and Running Noise Analysis..... | 248 |
| Examining the Results in Probe | 250 |